



***Dyno-Scan™ for Palm OS®***

# Quick Start

## ***Dyno-Scan™ for Palm OS®***

### **Need Help?**

For detailed product information check the electronic User Guide located on the Installation CD-ROM.

### **User Guide**

The User Guide is stored in Adobe PDF format. Adobe Acrobat Reader included on the Installation CD-ROM is used to open the User Guide.

### **Customer Support**

Product support is provided via email at [support@auterraweb.com](mailto:support@auterraweb.com).



©2003 Auterra, LLC. All rights reserved. Palm OS and HotSync are registered trademarks of Palm, Inc. All other company and trade names are registered trademarks of the respective owners.


# Follow these steps to get started with your Dyno-Scan™ for Palm OS®



## Step 1

Install software onto your Palm handheld


- Put the Dyno-Scan™ CD in your computer.
- Start the Palm Desktop Software that came with your Palm handheld.
- Click the 'Quick Install' button on the Palm Desktop Software and add Dyno-Scan.prc, MathLib.prc, and all the pdb files (i.e. Generic.pdb, Ford.pdb, ...) located on the Dyno-Scan™ CD. The button is simply labeled 'Install' on Palm Desktop Software versions prior to 4.1.
- HotSync® your Palm handheld.



## Step 2

Connect your Dyno-Scan™ to the Palm handheld

- A** Plug the HotSync® cable into the Palm handheld.
- B** Connect the HotSync® cable to the OBD II adapter and tighten the two thumb screws.
- C** Connect the OBD II cable to the OBD II adapter and tighten the two thumb screws.



## Step 3

Connect the Dyno-Scan™ to your vehicle

- Connect the OBD II cable to the vehicle.
- Start the Dyno-Scan™ software by tapping the Dyno-Scan™ icon on the Palm handheld.
- Press the 'Connect to Vehicle' button on the Dyno-Scan software.